

Wunder-Bar™

Automatic Bar Controls Inc.

TECHNICAL SERVICE BULLETIN

Date: 5/28/2020

Product: Spire 1.1 & Mustang Beverage Dispensers

Subject: Sanitizing & User Interface Screen Cleaning Update

Updated Process for sanitizing & cleaning user interface touch screen:

Using a 70% isopropyl alcohol wipe or Clorox Disinfecting Wipes are approved. You may gently wipe the hard, nonporous surface on your Spire 1.1 or Mustang dispenser touchscreen user interface display with a microfiber or soft towel. "Do not use Bleach". Avoid getting moisture in any opening, and do not submerge your product in any way in any cleaning agent.

"Windex or any other cleaner containing ammonia, vinegar or bleach will void the warranty,"



Additional Information: If you need further details please contact Wunderbar service at 1-866-986-3372 or Service@wunderbar.com